


## Instructions

# Mist AP21 All the Way to Paris 2025



---





Please read these instructions carefully and retain them for future reference to ensure the product is used correctly. For your own safety, please study each step of this instruction manual first. &Tradition is not responsible for any faults or damage caused by not following these instructions correctly. Do not modify this product in any way. If you have any questions or comments, please do not hesitate to contact us by mail on: [info@andtradition.com](mailto:info@andtradition.com)

&Tradition®

# Mist AP21

## All the Way to Paris 2025

---



08/25

Input 5.0V === 2A

Max 2 Watt dimmable LED (replaceable)

**Charging time:** 6 hours

**Operating time in highest light setting:** 10 hours



### Safety precautions

- Dispose of plastic bag from packaging and do not allow children to play with it.
- Keep product well out of children's reach.
- Do not place the cable within reach of small children or anywhere with a risk of falling over it.
- This lamp is for indoors use only. It can be taken outdoors, but must be kept, stored and charged indoors.
- Charge in dry environments only.
- Consult a professionally qualified electrician if in any doubt.
- Batteries must be disposed of according to local environmental laws for waste disposal.
- The luminaire is made insulation Class III. Therefore, it have to be charged by a SELV Circuit Plug driver. So the luminaire have the right protection when it is charged, or running on the mains.

### Contents

- A** Mist glass shade
- B** Mist marble base
- C** Light source
- D** Charging cable

### Cleaning instructions


- Wipe the surface with a soft, damp sponge or cloth, and wipe immediately with a dry cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, turpentine, household glass cleaner or cellulose thinner.

### Important

&Tradition will not take any responsibility for accidents or injuries that occurs due to use of incorrect battery/LED light bulb. The battery must be removed from the lamp before it is scrapped; the appliance must be disconnected from the supply mains when removing the battery; the battery must be disposed safely. For LED bulb and battery information or inquiry, please do not hesitate to contact &Tradition via mail on [info@andtradition.com](mailto:info@andtradition.com).


### Step 1 / 3

Place the light source (C) in the socket on the base (B).



### Step 2 / 3

Take the glass shade (A) and place over the base (B) and turn the glass to attach it to the base.



### Step 3 / 3

The product is now ready for use. To dim the light, tap to switch between three light levels 100%, 50% and 20%. If a different level is wanted, tap and hold the dimmer to smoothly dim for 100% and down.

